

MTM SHADE INSTALLATION VIEW



1、 Mark The Positions

Mark the position of the bracket installation on the window frame with a pen to ensure that both sides are aligned

2、 Mount The Wall Bracket

Use an electric drill to fix the bracket at the marked point to ensure a firm installation and avoid shaking.



3、 Insert The Headrail

Align the blinds headrail with the bracket, and then the bracket will grip and fix the headrail.

4、 Test Product Pull

Pull to test if the up and down retraction and opening and closing are smooth. If there is any lag, check if the bracket is installed flat

